


peroxy::lyser

peroxy::lyser monitors peracetic acid (PAA)

- · s::can plug & measure
- · measuring principle: amperometric (membrane covered)
- · ideal for all kinds of water treatment
- · long term stable and lowest maintenance in operation
- \cdot replacement of membrane only once a year
- · readings stable even at high fluctuations of pH, temperature and flow
- · strong surfactants are tolerated
- not cross sensitive to high concentrations of hydrogen peroxide
- · factory precalibrated
- · mounting and measurement in a flow cell
- · operation via s::can terminals & s::can software
- · additionally also measures temperature

recommended accessories				
part number	article name			
C-1-010-sensor	1 m connection cable for s::can physical and ISE probes			
D-315-xxx	con::cube			
D-319-xxx	con::lyte			
F-45-four	flow cell for four s::can physical probes			
F-46-four-iscan	i::scan flow cell for up to 3 additional s::can probes			
F-45-sensor	flow cell for s::can sensor			
S-11-xx-moni	moni::tool Software			







measuring principle	amperometric	housing material	PVC
measuring principle detail	potentiostatic 2-electrode system,		Stainless steel 1.4571
	membrane covered	weight (min.)	150 g
resolution	0.1 mg/l	dimensions (Ø x I)	35 x 208 mm
automatic compensation instrument	temperature	operating temperature	0 45 °C
response time	1.5 5 min.	storage temperature	0 45 °C
integration via	con::cube	operating pressure	0 1 bar
	con::lyte	installation / mounting	flow cell
	con::nect	process connection	quick connect
power supply	9 30 VDC	recomended flow	30 100 l/h
power consumption (typical)	0.5 W	pH range	1 6
power consumption (max.)	0.6 W	conformity - EMC	EN 61326-1
nterface to s::can terminals sys plug (IP67), RS485		protection class (-000)	IP67

drinking water						
		concentration ranges and sensor/probe	concentration ranges and sensor/probe type for this application			
		PAA	part number			
		[mg/l]				
peroxy::lyser	min.	0	E-515-1-000			
	max.	200				

www.s-can.at © s::can Messtechnik GmbH (2017)